

Ask for FM sensitivity scan level	1 	Ask for Bluetooth password	3 
Setup FM station sensitivity scan level: 1 or 2 or 3	1  2  3 	Setup current mode as Ideal mode	
Store FM/DAB memory	9 	Setup Auto Power ON for MASTER	
Delete FM/DAB memory	7 	Setup Auto Power ON for Aux Line Output	
Delete all FM/DAB memories	4 	Setup MASTER speaker output level: low	1 
Update DAB available stations	8 	Setup MASTER speaker output level: medium-low	2 
Reset DAB available stations	0 	Setup MASTER speaker output level: medium-high	3 
FM Forced Mono	C 	Setup MASTER speaker output level: max	4 
Disconnect Bluetooth ID	5 	Setup MASTER speaker output Mono	1 
Ask for Bluetooth ID	2 	Setup MASTER speaker output Stereo	2 
		Version	3 

